

WALL FIXING INSTRUCTIONS FOR VISUALUM

(Models VLI3, VLI1620, VLI2024, VLI2436, VLI13)

Measure the correct interval required between the screw points, depending upon whether the VISUALUM will be positioned horizontally or vertically.

Mark the two points on the wall with a pencil, at the height and position required. Ensure that the points are level. Please note also that the top edge of the VISUALUM, when in position, will be at some inches above these fixing points.

Insert the 2 screws supplied with VISUALUM into your wall at these points (using the plastic anchors provided if for solid walls or partitions, or using appropriate plugs if for hollow or other types of walls):

- The heads of the screws should protude from the wall by 3/16" for a secure fit.
- Ensure that these screw points are solid before attempting to hang the VISUALUM.

Place the central holes of the fixing points in the back of the VISUALUM over the screwheads, and guide the VISUALUM gently down into it's secured position.

